

**PROBLEM:**

**LEFT TEAR/ RIGHT BARE-SHAFT/ RIGHT BROADHEAD**



**CORRECTIONS:**

- Move rest to the right.
- Decrease load on cable guard (move cable guard towards arrow).
- Twist (L) yoke/ untwist (R) yoke.
- Move wheels left by changing spacing.

**LEGEND:**

PAPER TEAR



BARE SHAFT



FLETCHED SHAFT



ARROW  
(WITH BROADHEAD)



**PROBLEM:**

**RIGHT TEAR/ LEFT BARE-SHAFT/ LEFT BROADHEAD**



**CORRECTIONS:**

- Move rest to the left.
- Increase load on cable guard (move cable guard away from arrow).
- Twist (R) yoke/ untwist (L) yoke.
- Move wheels right by changing spacing.

**LEGEND:**

PAPER TEAR



BARE SHAFT



FLETCHED SHAFT



ARROW  
(WITH BROADHEAD)

